




# Envizio PRO Options

AccuBoom can help eliminate skips and overlaps in your field.



By monitoring where the sprayer or spreader has applied, AccuBoom automatically turns boom sections on when traveling into areas that have not been covered. It will also turn boom sections off when encountering previously applied areas or "No Spray Zones" such as waterways.



## AUTOBOOM *GLIDEseries*

Autoboom allows you to spray faster and more accurately by detecting changes in ground height and adjusting your boom height automatically. Not only can you decrease driver fatigue and wear and tear on your machine, but you increase the accuracy and coverage of the application. It's a simple one-touch operation, allowing you to just sit back and drive.

